- 1. Introduction to FMList Scanner
- 2. Setup
- 2.1.1 Setup Operating System onto the Raspberry Pi
- 2.1.2 Setup Operating System onto the Orange Pi 3 LTS
- 2.1.3 Setup Operating System onto the Orange Pi Zero 2
- 2.2 Setup on a pre-installed Pi or PC
- 2.3 System configuration after Setup of Operating System
- 3. Installation & setup of scanner software
- 4. Setup wiring: ATX-buttons, LEDs and Piezo-buzzer on Raspberry
- 5. Software hints for operation
- 6. Problems and possible solutions
- 7. Operation

# 4. Setup wiring: ATX-buttons, LEDs and Piezo-buzzer on Raspberry

Following notes are only for the Raspberry Pi 3B/3B+/4B **NOT** for other models!

## **GPIO** pins

The Raspberry Pi has two pin headers that are physically labeled (column *Physical* in following table). WiringPi software does number the pins differently (http://wiringpi.com/, column wPi). The right column with the physical pins 2, 4, 6, ..., 40 is lying on the outside of the Raspberry Pi. Pin 40 is located nearby the USB jacks. The left column with the odd numbered pins is lying inside of the Raspberry Pi board. You can get an overview of all pins with

#### gpio readall

#### produces

| ++++            |     |     |         |      |     |     |     |      |     |     |   |    |      |   |          |     |    |
|-----------------|-----|-----|---------|------|-----|-----|-----|------|-----|-----|---|----|------|---|----------|-----|----|
| +<br>  B<br>BCM |     | wPi | Name    | Mode | Į V | '   | Phy | /sic | cal | I   | ٧ | l  | Mode | I | Name     | wPi | -  |
| +               | +-  | +-  | +       |      | +   | -+- |     | ++-  |     | -+- |   | +- |      | + |          | -+  | -+ |
| +               | 1   | - 1 | 3.3v    |      |     | I   | 1   | П    | 2   | I   |   | 1  |      | 1 | 5v       |     | 1  |
| ١.              | 2 1 | 0 1 | CDA 1 L | TAI  |     |     | _   |      | 4   |     |   |    |      |   | <b>F</b> |     |    |
|                 | 2   | 8   | SDA.1   | TN   | 1   | .   | 3   | П    | 4   | ı   |   | 1  |      | 1 | 5V       | I   | ı  |
| <u>.</u>        | 3   | 9   | SCL.1   | IN   | 1   | .   | 5   | П    | 6   | I   |   |    |      |   | 0v       | 1   | 1  |
| <u>.</u>        | 4   | 7   | GPIO. 7 | IN   | 1   | .   | 7   | П    | 8   | I   | 0 | I  | IN   | I | TxD      | 15  | 14 |
| 1               |     | 1   | 0v      |      | l   | ļ   | 9   | П    | 10  | 1   | 1 | I  | IN   | I | RxD      | 16  | 15 |

| <br> -<br> - | 17  | l | 0   | I  | GPIO. 0 | 1   | IN   | I | 0 | I   | 11  | П    | 12  | I     | 0 | I  | OUT  | I     | GPIO. 1 | I  | 1   | 1  | 18 |
|--------------|-----|---|-----|----|---------|-----|------|---|---|-----|-----|------|-----|-------|---|----|------|-------|---------|----|-----|----|----|
| <u>.</u>     | 27  |   | 2   | I  | GPIO. 2 | I   | IN   | I | 0 | I   | 13  | П    | 14  | I     |   | I  |      | I     | 0v      | I  |     | l  |    |
| ا            | 22  | l | 3   |    | GPIO. 3 |     | IN   | l | 0 | I   | 15  | П    | 16  | I     | 0 | 1  | IN   | 1     | GPI0. 4 | I  | 4   | I  | 23 |
| ا            |     | l |     |    | 3.3v    |     |      | l |   | I   | 17  | П    | 18  | I     | 0 | 1  | IN   | 1     | GPIO. 5 | I  | 5   | I  | 24 |
| l<br>.l      | 10  | l | 12  |    | MOSI    |     | IN   | I | 0 | I   | 19  | П    | 20  | I     |   | 1  |      | l     | 0v      | I  |     | I  |    |
| l<br>.l      | 9   | l | 13  |    | MIS0    |     | IN   | I | 0 | I   | 21  | П    | 22  | I     | 1 | 1  | IN   | l     | GPI0. 6 | I  | 6   | I  | 25 |
| l<br>.l      | 11  | l | 14  |    | SCLK    |     | IN   | I | 0 | I   | 23  | П    | 24  | I     | 1 | 1  | IN   | l     | CE0     | I  | 10  | I  | 8  |
| l<br>.l      |     | l |     |    | 0v      |     |      | I |   | I   | 25  | П    | 26  | I     | 1 | 1  | IN   | l     | CE1     | I  | 11  | I  | 7  |
| l<br>.l      | 0   | l | 30  |    | SDA.0   |     | IN   | I | 1 | I   | 27  | П    | 28  | I     | 1 | 1  | IN   | l     | SCL.0   | I  | 31  | I  | 1  |
| <br> -<br> - | 5   | 1 | 21  |    | GPI0.21 |     | IN   | I | 1 | ı   | 29  | П    | 30  | I     |   | 1  |      | I     | 0v      | I  |     | l  |    |
| ا            | 6   | l | 22  |    | GPI0.22 |     | IN   | l | 1 | I   | 31  | П    | 32  | I     | 1 | 1  | 0UT  | 1     | GPI0.26 | I  | 26  | I  | 12 |
| <br> -<br> - | 13  | l | 23  | 1  | GPI0.23 |     | IN   | I | 0 | ı   | 33  | П    | 34  | I     |   | 1  |      | 1     | 0v      | I  |     | I  |    |
| <br>         | 19  |   | 24  | l  | GPI0.24 |     | IN   | I | 0 | I   | 35  | П    | 36  | I     | 0 | I  | 0UT  | I     | GPI0.27 | I  | 27  | l  | 16 |
| l<br>.l      | 26  | l | 25  | l  | GPI0.25 | 1   | IN   | I | 0 | ı   | 37  | П    | 38  | I     | 0 | I  | IN   | I     | GPI0.28 | I  | 28  | I  | 20 |
| <br>         |     |   |     | l  | 0v      |     |      | I |   | I   | 39  | П    | 40  | I     | 1 | I  | IN   | I     | GPI0.29 | I  | 29  | l  | 21 |
| +-           |     | + |     | +- |         | -+- |      | + |   | -+  |     | -++- |     | - + - |   | +- |      | +-    |         | +- |     | +- |    |
| •            | BCM | w | /Pi | l  | Name    |     | Mode | 1 | ٧ | I   | Phy | /si  | cal | 1     | ٧ | 1  | Mode | 1     | Name    | 1  | wPi | 1  |    |
|              | •   | + |     | +- |         | -+- |      | + |   | -+- | [   | Pi 3 | 3B+ | -+-   |   | +- |      | . + . |         | +- |     | +- |    |
| +            |     |   |     |    |         |     |      |   |   |     |     |      |     |       |   |    |      |       |         |    |     |    |    |

## **Connection of CPU fan**

The connection may differ depending on the model. Therefore observe the manufacturer's information!

## **Connection of Piezo-buzzer**

The buzzer is connected to the physical pins 12 (+) and 14 (ground / GND).

Test with

```
gpio mode 1 pwm # physical pin 12 corresponds to pin 1 in wiringPi
gpio pwmTone 1 2000 # sound on
gpio pwmTone 1 0
                   # sound off
```

### Connection of ATX buttons and LEDs

The ATX button for shutdown is connected to the physical pins 39 and 40. Test with

```
sudo systemctl stop gpio-input
                                  # 1st, deactivate the service
gpio mode 29 up
                                  # physical pin 40 corresponds to pin 29 in
wiringPi
gpio read 29
                                  # should deliver 1 if the button is not
pressed
                                  # should deliver 0 when the button is
pressed
```

The green LED is connected to physical pin 36 (wiringPi: 27), the ground to pin 34. The red LED is connected to physical pin 32 (wiringPi: 26), the ground to pin 30. Test with

```
gpio mode 27 output # wiringPi: 27 for green, 26 for red
gpio write 27 on  # corresponding LED (here: green) enlightens
gpio write 27 off
                    # corresponding LED gets dark
```

**ATTENTION**: the pin assignment of LEDs and buttons has been changed a few times - since the first scanner setup. Changes were necessary, e.g. depending on ATX cable pair and for special Raspberry Pi housings, e.g. the NesPi.

Reactivate the service after testing the buttons

```
sudo systemctl start gpio-input
```

From:

https://codingspirit.de/dokuwiki/ - coding spirit

Permanent link:

https://codingspirit.de/dokuwiki/doku.php?id=fmlist scanner:setup wiring Last update: 2022/06/18

